CINCINNATI® PRESS BRAKE OPERATOR



- Be sure you know your Press Brake
 - Capacity
 - Controls
 - Operating Modes
 - Safeguarding
- Nnow and understand the job you are about to perform
 - Material placement
 - Feeding and movement of material being formed
- Never place your hands in the die area.
- Make sure no one is in the backgage area at the rear of the machine.
- De sure tooling, Press Brake and gaging are properly set for the job.
- Always cycle the Press Brake at least twice before each shift and each job, without a part in the dies.
- Neep die area free of all unnecessary materials and tools.
- Do not hang tools on the ram.
- Make certain adequate safeguarding is available and used.
- > Keep your body clear of the workpiece.
- > Keep work area clean and orderly.
- Neep alert keep your mind on the job.
- Make certain all persons are clear of the machine and material before operating.
- Make certain hand tools and personal protective devices are available and used.
- When you leave your Press Brake, always:
 - Place the ram at the bottom of the stroke or block under the ram.
 - Turn operator controls to "OFF" and remove the key.
 - Turn the main drive "OFF".

FAILURE TO FOLLOW SAFE PRESS BRAKE OPERATING PROCEDURES may result in serious injury to you or another employee.